

Kodak K4500

Digital Camera Battery Charger

Effective: June 10, 2009



Six adapter plugs included for worldwide 110-240 volt power source

Designation	Kodak Digital Camera Battery Charger Model K4500				
Dimensions	L 110.5 mm x W 66.7 mm x H 30.5 mm (excluding plug)				
Weight	101 g (excluding plug)				
Battery Size Application	2 x AA or 1 x KAA2HR size batteries				
Battery Type	Ni-MH				
Display Device	Solid red:	Battery is discharging			
	Flashing yellow:	Battery is charging			
	Flashing green:	Battery is fully charged. Charging complete.			
	Flashing red:	(Error remove battery from charger)			
Charge Termination	Delta voltage detection Peak voltage detection Protection timer				
Input Power	100-240 V AC/50-60 Hz, 9W				
Output-Charge Current	DC 1200 mA ±10%				
Charge Time (approx.)	Battery Size / Type	Charge Time (minutes)	Battery Size / Type	Charge Time (minutes)	
	AA 2300 mAh	120	AA 1850 mAh	95	
	AA 2100 mAh	110	AA 1600 mAh	85	
Charge Protection	1) Timer 2) Over voltage protection				
Compliance	1) Safety: Complies with IEC 60335-1, IEC 60335-2, UL 1310 2) EMI: Complies with EN 55022, EN 55024, EN 61000-3-2, EN 61000-3-3, FCC Part 15				
Approvals	UL, FCC, CE, GS, C-Tick, KETI, PSE, CQC, NOM, GHOST				

The Data in this publication represents product tested under the conditions specified. They do not represent standards or specifications which must be met by Eastman Kodak Company. Company reserves the right to change and improve product characteristics at any time.

For more information, contact Eastman Kodak Company, 343 State Street, Rochester NY 14650-0811
Phone 1-800-242-2424. www.kodak.com/go/batteries

© Eastman Kodak Company, 2009

Kodak is a trademark.

Kodak